



Press **Update**.

A Windows Explorer directory will then appear, and you must select the firmware revision that needs to be downloaded.

If the required firmware version is not displayed then you can "browse" your hard drive to find it. The firmware file has the structure 8860-FW-X.X.X.X.tgz.gpg

Name	Date modified	Type	Size
2.1.0.22	2/24/2020 9:50 AM	File folder	
GC dirver 3.1 SR1	2/24/2020 9:50 AM	File folder	
8860-FW-2.0.0.391.tgz.gpg	9/18/2019 2:59 AM	GPG File	1,673,174 KB

After you have selected the correct file the firmware will automatically be downloaded.

After the download is finished the GC will reboot and the firmware update is complete.